




PHOTO FRAME

WHAT'S IN THE BOX?


- 1x Frame A
- 1x Standard B

This instruction is suitable for all sizes.





1. Check that you have all the parts.

2. Break out the loose parts and place the photo on the side with the hanging holes in the inside of the frame. Then fold the frame in half.




Optional Steps



3. Fold the bulges over. Make sure that the bulges fall completely flat in the recesses. The picture frame can now be hung.

4. By default, fold it at a 90-degree angle. Then slide the stand into the hole of the photo frame



5. The photo frame can be used both portrait and landscape.